



CURTIS

Manual

Models **1266A/1266R**

Electronic Motor Controllers



Curtis Instruments, Inc.
200 Kisco Avenue
Mt. Kisco, NY 10549
www.curtisinstruments.com



Read Instructions Carefully!

Specifications are subject to change without notice.

© 2014 Curtis Instruments, Inc. ® Curtis is a registered trademark of Curtis Instruments, Inc.


© The design and appearance of the products depicted herein are the copyright of Curtis Instruments, Inc.

53123 Rev C 11/14

The Curtis Difference 
You feel it when you drive it

CONTENTS

1. OVERVIEW	1
2. INSTALLATION AND WIRING	4
Mounting the Controller	4
Connections: Low Current.....	6
Connections: High Current	7
Wiring: Controller	8
Wiring: Throttle.....	10
Wiring: Drivers	12
Wiring: Pedal Interlock Switch.....	13
Contactor, Switches, and Other Hardware.....	14
3. PROGRAMMABLE PARAMETERS	15
Programmable Parameter Menus.....	16
5. MONITOR MENU	30
5. INSTALLATION CHECKOUT	32
6. TUNING GUIDE	34
7. DIAGNOSTICS AND TROUBLESHOOTING	48
8. MAINTENANCE.....	51
APPENDIX A Vehicle Design Considerations	
APPENDIX B Programming Devices	
APPENDIX C Specifications, 1266A and 1266R Controllers	



FIGURES

FIG. 1: Curtis 1266A electronic motor controller.....	1
FIG. 2: Mounting dimensions, Curtis 1266A/R controller	4
FIG. 3: Standard wiring: Curtis 1266A/R controller.....	8
FIG. 4: Wiring for 3-wire potentiometer throttle	10
FIG. 5: Wiring for 0–5V throttle	10
FIG. 6: Wiring for electronic throttle	11

1

OVERVIEW

Curtis 1266A and 1266R controllers are motor speed controllers designed for use in a variety of transport vehicles. These programmable controllers are simple to install, efficient, and cost effective. Typical applications include golf carts, small utility vehicles, and light on-road vehicles.

The 1266A and 1266R controllers offer smooth, cost effective control of motor speed and torque. The speed sensor input allows superior closed-loop control for regulating vehicle speed. Unique braking parameters allow simple, intuitive deceleration tuning. A full-bridge field winding control stage is combined with a half-bridge armature power stage to provide solid state motor reversing and regenerative braking power without additional relays or contactors.

Fig. 1 *Curtis 1266R electronic motor controller. The 1266A model looks the same, except for a slightly thinner baseplate.*



These controllers are fully programmable by means of a Curtis programming device. Use of a programmer provides diagnostic and test capability as well as configuration flexibility and the ability to easily transfer settings from one controller to another.

Like all Curtis motor controllers, the 1266 A and 1266 R offer superior operator control of the vehicle's motor drive speed. **Features include:**

- ✓ Adjustable parameters enable custom optimization of speed, torque, and braking control
- ✓ Power MOSFET technology provides smooth, silent, efficient, and cost-effective operation
- ✓ Half-bridge armature and full-bridge field provide regenerative braking down to near zero speed
- ✓ MultiMode™ input allows choice of two vehicle operating personalities, with vehicle top speed controlled and limited in each mode
- ✓ Vehicle speed control is enhanced through feedback from a Hall effect speed sensor
- ✓ Overspeed braking (regenerative) limits speed while driving downhill
- ✓ Anti-rollback function provides improved control when throttle is released on hills
- ✓ Anti-stall function helps prevent motor commutator damage
- ✓ High pedal disable (HPD) interlocks prevent vehicle runaway at startup
- ✓ WalkAway™ braking feature limits any stopped or key-off rolling to a very low speed (1266A models only)
- ✓ Tow switch disables WalkAway™ for towing of vehicle
- ✓ EM brake driver output for use with vehicles equipped with electromagnetic parking brakes
- ✓ Timed shutdown of main contactor after pedal is released and vehicle has stopped
- ✓ Programmable current boost function allows extra power at startup
- ✓ Programmable coil drivers provide adjustable pull-in and holding voltages to EM brake and main contactor coils
- ✓ Driver outputs are short circuit protected and provide built-in coil spike protection

- ✓ Warning alarm sounds steady in reverse, intermittent during WalkAway™ braking
- ✓ Rugged package rated at IP5X
- ✓ Fully compatible with Curtis 1311, 1313, and 1314 programmers for parameter adjustment, tuning, test, and diagnostics
- ✓ Meets or exceeds EEC fault detect requirements; fault detection and diagnostic reporting via a Curtis programmer include (partial list):
 - Main contactor weld check and driver check
 - EM brake driver/coil checks
 - Throttle and wiring faults
 - Open or shorted motor field wiring
 - Open motor armature wiring
 - Over-temperature
 - Missing or failed speed sensor
 - Armature drive failure
- ✓ Extensive system monitor capabilities via a Curtis programmer include (partial list):
 - Battery voltage
 - Throttle input
 - Direction and throttle switch operation
 - Motor field and armature currents
 - Controller heatsink temperature

Familiarity with your Curtis controller will help you install and operate it properly. We encourage you to read this manual carefully. If you have questions, please contact the Curtis office nearest you.

2


INSTALLATION AND WIRING

MOUNTING THE CONTROLLER

The outline and mounting hole dimensions for the 1266A/R controller are shown in Figure 2.

The controller can be oriented in any position; however, **the location should be carefully chosen to keep the controller as clean and dry as possible. If a clean, dry mounting location cannot be found, a cover must be used to shield the controller from water and contaminants.** When selecting the mounting position, be sure to also take into consideration that access is needed at the side of the controller to plug the programmer into its connector.

Fig. 2 *Mounting dimensions, Curtis 1266 A/R controller.*



To ensure full rated power, the controller should be fastened to a clean, flat metal surface with three 6 mm (1/4") diameter screws, using the holes provided. Although not required, a thermal joint compound can be used to improve heat conduction from the controller heatsink to the mounting surface.

You will need to take steps during the design and development of your end product to ensure that its EMC performance complies with applicable regulations; suggestions are presented in Appendix A.



The 1266 A/R controller contains ESD-sensitive components. Use appropriate precautions in connecting, disconnecting, and handling the controller. See installation suggestions in Appendix A for protecting the controller from ESD damage.



Working on electric vehicles is potentially dangerous. You should protect yourself against runaways, high current arcs, and outgassing from lead acid batteries:

RUNAWAYS — Some conditions could cause the vehicle to run out of control. Disconnect the motor or jack up the vehicle and get the drive wheels off the ground before attempting any work on the motor control circuitry.

HIGH CURRENT ARCS — Electric vehicle batteries can supply very high power, and arcs can occur if they are short circuited. Always open the battery circuit before working on the motor control circuit. Wear safety glasses, and use properly insulated tools to prevent shorts.

LEAD ACID BATTERIES — Charging or discharging generates hydrogen gas, which can build up in and around the batteries. Follow the battery manufacturer's safety recommendations. Wear safety glasses.


CONNECTIONS

Low Current Connections

Two low current connectors are built into the controller: a 16-pin connector and a 4-pin connector. They are located on the side of the controller.

The **16-pin** connector provides the logic control connections. The mating connector is a 16-pin Molex Mini-Fit Jr. connector p/n 39-01-2165 using type 5556 terminals. The appropriate wire gauge is 18–24 AWG.

Note: The +15V supply (pin J1-10) should never be used to power any external systems other than the speed sensor.



J1-1	Speed	<i>input signal from motor speed sensor</i>
J1-2	EM Brake	<i>EM brake driver low-side output</i>
J1-3	Warning Alarm	<i>alarm low-side driver output</i>
J1-4	Pot High	<i>+5V supply through 453Ω</i>
J1-5	Throttle	<i>throttle input</i>
J1-6	Pot Low	<i>453Ω to ground</i>
J1-7	Main Contactor	<i>contactor coil driver low-side output</i>
J1-8	Charger Inhibit	<i>input from charger inhibit switch</i>
J1-9	Ground	<i>B- ground for motor speed sensor</i>
J1-10	+15V	<i>+15V supply</i>
J1-11	Reverse	<i>input from reverse switch</i>
J1-12	Forward	<i>input from forward switch</i>
J1-13	Pedal Interlock	<i>input from pedal switch, wired to throttle</i>
J1-14	Mode Switch	<i>input from mode switch</i>
J1-15	KSI	<i>keyswitch input</i>
J1-16	Logic Power	<i>power to controller logic</i>

J2-1	Rx Data
J2-2	B-
J2-3	Tx Data
J2-4	+15V


**J2**

A **4-pin** low power connector is provided for an optional programmer. A complete handheld programmer kit, including the appropriate connecting cable with mating connector, can be ordered from Curtis. If a handheld programmer is already available but has an incompatible cable, the appropriate connecting cable can be ordered as a separate part.

If a 1314 PC programming station is used, the 1309 interface box and cable connect the computer to the controller.

High Current Connections

Three tin-plated solid copper bus bars are provided for the high current connections to the battery (**B+** and **B-**) and the motor armature (**M-**). Cables are fastened to the bus bars by M8 bolts. The 1266 A/R case provides the capture nuts required for the M8 bolts. The maximum bolt insertion depth below the surface of the bus bar is 13 mm (1/2"). Bolt shafts exceeding this length may damage the controller. The torque applied to the bolts should not exceed 16.3 N·m (12 ft-lbs).



Two 1/4" quick connect terminals (**S1** and **S1**) are provided for the connections to the motor field winding.

WIRING: Standard Configuration

Figure 3 shows typical wiring for 1266A and 1266R controllers. All 1266A models include a built-in WalkAway™ function, which limits any stopped or key-off rolling to a very low speed. The 1266R models do not include WalkAway™.




Fig. 3 Standard wiring configuration for Curtis 1266A/R controller.

Standard Power Wiring

Motor armature winding is straightforward, with the armature's **A1** connection going to the controller's B+ bus bar and the armature's **A2** connection going to the controller's M- bus bar.

The motor's field connections (**S1** and **S2**) to the controller are less obvious. The direction of vehicle travel with the forward direction selected will depend on how the **S1** and **S2** connections are made to the controller's two field terminals and how the motor shaft is connected to the drive wheels through the vehicle's drive train.

Standard Control Wiring

Wiring is shown in Figure 3 for the most commonly used components. Wiring for alternative throttles is shown in the following pages.

The main contactor coil must be wired directly to the controller as shown in Figure 3. The controller uses the main contactor coil driver output to remove power from the controller and motor in the event of various faults. **If the main contactor coil is not wired to pin J1-7, the controller will not be able to open the main contactor in serious fault conditions and the system will therefore not meet EEC safety requirements.**

The switch inputs are all powered by the battery pack, as shown in Figure 3.

WIRING: Throttle

Various throttles can be used with the 1266A/R controller, including 5k Ω 3-wire potentiometers, 0–5V throttles, and electronic throttles.


The controller looks for a voltage signal at the throttle input (pin J1-15), with vehicle speed increasing with increased throttle voltage. All throttle fault protection is accomplished by monitoring the throttle input. This provides throttle fault protection that meets all EEC requirements. Thus, no additional fault protection is required on any throttle type used with the 1266A/R controller.

If the throttle you are planning to use is not covered, contact the Curtis office nearest you.

3-Wire Potentiometer (5k Ω –10k Ω) Throttle

The 3-wire potentiometer is used in its voltage divider mode, with the voltage source and return being provided by the controller. Pot High (pin J1-4) provides a current limited 5V source to the pot, and Pot Low (pin J1-6) provides the return path. The pot wiper is then connected to the Throttle input (pin J1-5). Potentiometers with total resistance values between 5k Ω and 10k Ω can be used. Wiring is shown in Figure 4.

Fig. 4 Wiring for 3-wire potentiometer throttle.




This wiring is also shown in the standard wiring diagrams, Figures 3a and 3b.

0–5V Throttle

The active range for the 0–5V throttle is set by the parameters Throttle 0% and Throttle 100%, and is measured relative to B-. Wiring is shown in Figure 5.


Fig. 5 Wiring for 0–5V throttle.



Electronic Throttle

Pot High (pin J1-4) supplies pure 5V, with Pot Low (pin J1-6) providing the ground. As with all throttles, the input comes from the Throttle input (pin J1-5).

Fig. 6 *Wiring for electronic throttle.*



WIRING: Drivers

The 1266 controller provides three drivers (at Pins 2, 3, 7) for the EM brake, warning alarm, and main contactor. These three outputs are low-side drivers, designed to energize inductive coils or a piezoelectric reverse alarm. The warning alarm and EM brake are optional functions.

For the warning alarm driver (pin J1-3), it is necessary to specify the connected coil voltage at the nominal battery pack voltage. The main contactor driver's coil voltage is set by the Main Pull-In % and Main Holding % parameters, as a percentage of the nominal battery pack voltage. Similarly, the EM brake driver's coil voltage is set by the EM Pull-In % and EM Holding % parameters. See Section 3 for more information on programming these parameters.

A coil suppression diode is provided internally to protect two of the drivers (pins J1-2, J1-7) from inductive spikes generated at turn-off. To take advantage of the controller's internal coil suppression diode, the coils must be wired such that the return path to the drivers cannot be opened by any switches or contactors, as shown in the standard wiring diagram (page 8).

DRIVER	PIN	RATED CURRENT	RATED LOAD VOLTAGE	INTERNAL DIODE PROTECTION
Main Contactor	J1-7	2.0 A	48V, 36V, 24V, 12V	yes
Warning Alarm	J1-3	0.02 A	B+	no
EM Brake	J1-2	2.0 A	48V, 36V, 24V, 12V	yes

The driver loads are not limited to contactor coils. Any load can be connected to a pin J1-3 or J1-7 driver as long as it does not exceed the current rating.

For information on programming the various driver-related parameters, see Section 3: Programmable Parameters.

Main Contactor Driver

The main contactor driver (pin J1-7) pulls low when (a) the tow/store switch, keyswitch input, and pedal interlock switch are enabled, (b) a direction is selected, and (c) throttle is applied; it stays low until near zero speed at zero throttle, or until a critical fault occurs. This wiring is shown in the standard wiring diagrams (pages 8, 9).

The main contactor driver's output is pulse width modulated at the coil-holding voltage set by the Main Holding % parameter. The pull-in voltage set by the Main Pull In % parameter is used in place of the holding voltage for the first 100 ms.

Warning Alarm Driver

The alarm driver (pin J1-3) pulls low when the reverse direction switch is applied. This driver is designed to drive a reverse signal beeper or piezoelectric buzzer that operates when the vehicle is traveling in reverse or during WalkAway™ operation. It can also be programmed to give a warning during anti-rollback.

Electromagnetic Brake Driver

The EM brake driver (pin J1-2) becomes active (low) when the vehicle is commanded into motion so as to activate the brake coil and pull in the brake.

The driver's output is pulse width modulated at the coil holding voltage set by the Holding Voltage parameter. The pull-in voltage set by the Pull-In Voltage parameter is used in place of the holding voltage for the first 100 milliseconds.

The EMB Delay parameter allows for the adjustment of a time delay before the brake engages after the vehicle is stopped or has slowed below the threshold set by the EMB Speed Value parameter.

WIRING: Pedal Interlock Switch

Controller output is possible only when the pedal interlock input (pin J1-13) is pulled to B+. The pedal interlock switch is connected to the throttle mechanism, thus guaranteeing zero controller output when the operator releases the throttle. This adds a safety feature to protect against throttle failures that could otherwise cause unintended controller output (vehicle motion).

CONTACTOR, SWITCHES, and OTHER HARDWARE

Main Contactor

A main contactor is required for use with any 1266 A/R controller. The main contactor allows the controller and motor to be disconnected from the battery. This provides a significant safety feature in that the battery power can be removed from the drive system if a controller or wiring fault is detected. A single-pole, single-throw (SPST) contactor with silver-alloy contacts is recommended for use as the main contactor. The coils must be specified at the nominal battery pack voltage, with a continuous rating.

A 500 Ω resistor must be used across the contactor to precharge the capacitors; the resistor wattage must be such that it can accept the maximum system voltage (typically 10W @ 48V).

Keyswitch and Run/Store Switch

The vehicle should have a keyswitch to enable/disable driving each time the vehicle is used. The run/store switch, on the other hand, is typically located in an out-of-the-way location and left on except when the vehicle will be stored (during the winter, for example) or is being towed. The keyswitch and the run/store switch provide current to drive the various coils as well as the controller's internal logic circuitry and must be rated to carry these currents.

Forward, Reverse, Mode, Pedal Interlock, and Charger Inhibit Switches

These input switches can be any type of single-pole, single-throw (SPST) switch capable of switching the battery voltage at 25 mA.

Circuitry Protection Devices

To protect the control circuitry from accidental shorts, a low current fuse (30 A for the 1266A, 10 A for the 1266R) should be connected in series with the battery feed to the run/store switch. Additionally, a high current fuse should be wired in series with the main contactor to protect the motor, controller, and batteries from accidental shorts in the power system. The appropriate fuse for each application should be selected with the help of a reputable fuse manufacturer or dealer. The standard wiring diagram (see page 8) shows the recommended fuse locations.

Speed Sensor

A speed sensor is required for use with any 1266 A/R controller. The speed sensor must be of a pulse type, and must interface to the controller with an open collector NPN transistor output. The most common sensor type will be a Hall effect switch IC, such as the Allegro type UGN3132 or Micro Switch type SS11; these work with an eight-pole (four pulses per revolution) ring magnet attached to the motor shaft. Other pole configurations can be accommodated by programming the Tacho Poles parameter to match the sensor magnet. Linear output sensors such as PM tachogenerators and variable reluctance gear tooth sensors ("magnetic pickups") are unsuitable.

A Curtis Application Note is available with more detailed information on the speed sensor requirements.

3

PROGRAMMABLE PARAMETERS

The 1266 A/R controller's programmable parameters allow the vehicle's performance characteristics to be customized to fit the needs of individual vehicles or vehicle operators. Programming can be done with a Curtis 1311 or 1313 handheld programmer or a Curtis 1314 PC Programming Station. .

Curtis offers four versions of each of these programmers: User, Service, Dealer, and OEM versions. See Appendix B for more information about the programmers.

The 1266 A/R controllers allow operation in two distinct modes: Mode 1 and Mode 2. These modes can be programmed to provide two different sets of operating characteristics, which can be useful for operating in different conditions—such as slow precise indoor maneuvering in one mode, and faster, long distance, outdoor travel in the other mode.

Eleven parameters can be configured independently in the two modes:

- Main Current Limit (M1, M2)
- Boost Current Limit (M1, M2)

- Max Speed (M1, M2)
- Acceleration Rate (M1, M2)
- Deceleration Rate (M1, M2)

- Brake Minimum (M1, M2)
- Brake Maximum (M1, M2)
- Brake Start (M1, M2)
- Brake End (M1, M2)
- Brake Map (M1, M2)

- Field Minimum (M1, M2).

In the following descriptions, the 1266 A/R's parameters are presented in the order in which they appear in the programmer menus. **Many of the parameters are interdependent. In the descriptions in this section, these interdependencies are only briefly noted. For a more thorough discussion of how they work together, see Section 6: Tuning Guide.**

Table 3 Programmable Parameter Menus

CURRENT LIMITS MENUp. 17

- M1 Main C/L
- M1 Boost C/L
- M2 Main C/L
- M2 Boost C/L
- Boost Time
- Regen C/L
- Plug C/L
- WalkAway C/L

MODE 1 MENUp. 18

- M1 Max Speed
- M1 Accel
- M1 Decel
- M1 Brake Min
- M1 Brake Max
- M1 Brake Start
- M1 Brake End
- M1 Brake Map

REVERSE MENUp. 20

- Reverse Speed
- Reverse Accel
- Reverse Decel
- Reverse Brake Min
- Reverse Brake Max
- Reverse Brake Start
- Reverse Brake End
- Reverse Brake Map

MODE 2 MENUp. 21

- M2 Max Speed
- M2 Accel
- M2 Decel
- M2 Brake Min
- M2 Brake Max
- M2 Brake Start
- M2 Brake End
- M2 Brake Map

VEHICLE-MOTOR MENUp. 22

- Motor RPM / Vehicle Speed
- Tacho Poles

BATTERY MENUp. 22

- Overvoltage Min
- Low Voltage Max
- Low Voltage Margin

THROTTLE MENUp. 23

- HPD Threshold
- Throttle Map
- Throttle 0%
- Throttle 100%
- Throttle Fault Lo
- Throttle Fault Hi
- 5v Enable

WARNING OPTIONS MENUp. 24

- Overvoltage Beep
- Anti-Rollback Beep

FIELD MAPS MENU

- Positive Field Map**p. 25
 - M1 Field Min
 - Reverse Field Min
 - M2 Field Min
 - Field Map Start
 - Field Map
 - Field Max
 - Field Map End
- Negative Field Map**p. 26
 - Neg Field Map Start
 - Neg Field Map
 - Neg Field Max
 - Neg Field Map End

EM BRAKE MENUp. 27

- EM Brake
- EMB Pull In %
- EMB Holding %
- EMB Delay
- EMB Speed Check
- EMB Speed Value

FIELD BRAKE MENUp. 28

- Field Brake
- Field Brake Speed
- Field Brake Max
- Field Brake Rate

MAIN CONTACTOR MENUp. 29


- Main Drop Out Time
- Main Pull In %
- Main Holding %

CURRENT LIMITS MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
M1 Main C/L	100–275 A*	<p>Defines the maximum current the controller will supply to the motor during drive operation in Mode 1. This parameter can be used to reduce the maximum torque applied to the drive system by the motor.</p> <p>The Main C/L is adjustable from 100 A up to the controller's full rated current. The full rated current depends on the controller model; see Table C-1.</p>
M1 Boost C/L	100–300 A*	<p>Defines the maximum current the controller will supply to the motor during boost operation in Mode 1. Boost operation provides an increased current for the duration defined by the Boost Time parameter.</p>
M2 Main C/L	100–275 A*	See description of M1 Main C/L.
M2 Boost C/L	100–300 A*	See description of M1 Boost C/L.
Boost Time	0–10 s	<p>Defines the duration of each instance of boost. To reset the boost time, the measured armature current must be below 90% of Main C/L. It takes eight times the Boost Time to reach the full Boost Time capability.</p> <p>If Main C/L = 275A, Boost C/L = 300A, and Boost Time = 10s, the maximum current will be 300A for 10 seconds; at the expiration of Boost Time, the current will again be limited at 275A.</p> <p>After the armature current is below ~245A for 8 seconds, 1 second of boost will be available. After the armature current is below ~245A for 80 seconds, the full 10 seconds of boost will be available.</p>
Regen C/L	50–275 A*	<p>Defines the maximum current the controller will supply to the motor during regen braking operation. During regen braking, this parameter controls the regen current from the motor's armature into the battery.</p> <p>Regen braking is the normal mode of braking.</p> <p>The Regen C/L is adjustable from 50 A up to the controller's full rated current. The full rated current depends on the controller model; see Table C-1.</p>
Plug C/L	50–275 A*	<p>Defines the maximum current the controller will supply to the motor during plug braking operation. During plug braking, this parameter controls the plug current from the motor's armature.</p> <p>Plug C/L limits the armature current during WalkAway™ operation (available only on 1266A models).</p> <p>The Plug C/L is adjustable from 50 A up to the controller's full rated current. The full rated current depends on the controller model; see Table C-1.</p>
WalkAway C/L	6–10 A	<p>Sets the maximum field current applied during WalkAway™ operation. The WalkAway™ function applies field current to slow a vehicle that is detected as moving while the main contactor is open. The motor force created from this function is intended to limit the vehicle's rolling speed, but may not be sufficient to slow heavy vehicles on steep slopes.</p> <p>The warning alarm is pulsed to provide an audible indication that the vehicle is rolling.</p> <p>The WalkAway™ function is available only on 1266A models.</p>

* Note: Upper limit of range is model-specific.

MODE 1 MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
M1 Speed	4–62	Defines the maximum forward speed of the vehicle in Mode 1. The units are mph or km/h, depending on the setting of the Motor RPM / Vehicle Speed parameter; see Vehicle-Motor menu.
M1 Accel	0.6–5.0 s	The acceleration rate defines the time, in seconds, for the controller to accelerate from 0% output to 100% output when the vehicle is traveling forward. A larger value represents a longer acceleration time and a gentler start. Fast starts can be achieved by reducing the acceleration time, i.e., by setting the acceleration rate to a smaller value.
M1 Decel	0.2–30.0 s	The deceleration rate defines the time, in seconds, for the controller to decelerate from 100% output to 0% output when the vehicle is traveling forward. A larger value represents a longer deceleration time and gentler vehicle slowing. Quick stops can be achieved by reducing the deceleration time, i.e., by setting the deceleration rate to a smaller value. If the vehicle is slowing quicker than the programmed deceleration rate (for example, at zero throttle while traveling up a hill) the output will decay at a rate of 0.8 seconds.
M1 Brake Min	10–100 %	The Brake Minimum parameter sets the maximum regen current at low speeds, and is applicable from Brake Start speed to zero speed. The value is a percentage of the full regen current. Brake Min is used to soften vehicle braking at low speeds. A low value will limit the braking at low speeds to provide a soft deceleration. A very low value may prevent the vehicle from coming to a stop from pedal-up braking on an incline, while a very high value may cause the vehicle to brake abruptly.
M1 Brake Max	10–100 %	The Brake Maximum parameter sets the maximum regen current at high speeds, and is applicable at speeds at and above the Brake End speed. The value is a percentage of the full regen current. Brake Max is used to strengthen vehicle braking at high speeds. A high value will provide greater braking power at high speeds. A very low value may prevent the vehicle from successfully limiting speed down a hill, while a very high value may cause excessive braking force at high speeds. Note: Brake Max should be set to higher value than Brake Min.
M1 Brake Start	0–62	Defines the vehicle speed at which the brake map (see below) starts to increase from the Brake Min value. Increasing the Brake Start value increases the speed at which the controller's braking power reaches the Brake Min setting, resulting in a larger speed range with soft braking. The units are mph or km/h, depending on the setting of the Motor RPM / Vehicle Speed parameter; see Vehicle-Motor menu.
M1 Brake End	0–62	Defines the vehicle speed at which the brake map (see below) reaches the Brake Max value. Increasing the Brake End value allows the controller to use a higher braking power at higher speeds. Decreasing the Brake End value increases the braking torque the vehicle can produce at medium speeds. The units are mph or km/h, depending on the setting of the Motor RPM / Vehicle Speed parameter; see Vehicle-Motor menu. Brake Map End should be set higher than Brake Map Start.

MODE 1 MENU, cont'd

PARAMETER	ALLOWABLE RANGE	DESCRIPTION
M1 Brake Map	20–80 %	<p>The brake map parameter defines the shape of the brake map curve. The value set for this parameter is a percentage of the regen current between the Brake Min and Brake Max values, at the point that is halfway between the Brake Start and Brake End speeds (the “Brake Map Midpoint”), as shown here. The Brake Map curve is the maximum allowed regen current, and the shaded gray area below it is the operating range.</p> 
		<p>With the Brake Map set at 50%, the motor’s regen current limit decreases linearly with decreasing speed, providing a consistent rate of softening in braking power. Decreasing the Brake Map setting reduces the regen current attainable at medium speeds. Because the regen current limit is reduced as the speed is reduced, the motor will brake more gently as the vehicle approaches a stop.</p> <p>Note: Brake Start and Brake End refer to the vehicle speeds at which the vehicle “starts” to increase and “ends” increasing. From the operator’s perspective, however, braking begins at the point on the curve corresponding to the vehicle’s speed when braking is initiated and then follows the curve toward Brake Start. The braking force is typically set to decrease as the vehicle slows down.</p>


REVERSE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Reverse Speed	4–16 mph or km/h	The eight parameters in the Reverse Menu function exactly like the eight corresponding parameters in the Mode 1 Menu; see pages 18–19.
Reverse Accel	0.6–5.0 s	
Reverse Decel	0.2–30.0 s	
Reverse Brake Min	10–100 %	
Reverse Brake Max	10–100 %	
Reverse Brake Start	0–16 mph or km/h	
Reverse Brake End	0–16 mph or km/h	
Reverse Brake Map	20–80 %	

MODE 2 MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
M2 Speed	4–16 mph or km/h	The eight parameters in the Mode 2 Menu function exactly like the eight corresponding parameters in the Mode 1 Menu; see pages 18–19.
M2 Accel	0.6–5.0 s	
M2 Decel	0.2–30.0 s	
M2 Brake Min	10–100 %	
M2 Brake Max	10–100 %	
M2 Brake Start	0–16 mph or km/h	
M2 Brake End	0–16 mph or km/h	
M2 Brake Map	20–80 %	

VEHICLE — MOTOR MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Motor RPM / Vehicle Speed	50–1024	<p>This parameter is a conversion factor used to generate a vehicle speed estimate from the speed sensor input (motor RPM signal).</p> <p>Use these equations to calculate the value to enter for the Motor RPM / Vehicle Speed parameter:</p> <p style="text-align: right;">For English units (mph): $\frac{336 \times \text{gear ratio}}{\text{tire diameter (inches)}}$</p> <p style="text-align: right;">For metric units (km/h): $\frac{530 \times \text{gear ratio}}{\text{tire diameter (cm)}}$</p>
Tacho Poles	4–20	The Tachometer Poles parameter configures the speed sensor, and should be set to the number of magnetic poles in the speed sensor magnet. See speed sensor description (page 14) for information about sensor types.

BATTERY MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Overvoltage Min	40–65 V	<p>Sets the overvoltage protection threshold for the electronic system. This parameter determines when regen should be cut back to prevent damage to batteries and other electrical system components due to overvoltage.</p> <p>A non-adjustable internal threshold also exists, to prevent damage within the controller.</p>
Low Voltage Max	27–45 V	Sets the undervoltage threshold to protect the system from operating at voltages lower than its electronics were designed for. At the set threshold voltage, the drive current will taper off until it reaches the controller's internal threshold for safe operation. This ensures proper operation of all electronics whenever the vehicle is driven.
Low Voltage Margin	2–10 V	Sets the threshold below Low Voltage Max at which full cut-off will occur.

THROTTLE MENU

PARAMETER	ALLOWABLE RANGE	DESCRIPTION
HPD Threshold	0–25 %	<p>Defines the percentage of the full throttle range above which the HPD (High Pedal Disable) function is invoked. The HPD function prevents the vehicle from moving in the event of an incorrect sequence of operator inputs or from moving at power-up as a result of problems in the throttle linkage or components.</p> <p>Note: Throttle must be applied after the key and a direction switch are turned on.</p>
Throttle Map	20–80 %	<p>The Throttle Map parameter modifies the vehicle's response to the throttle input. As shown in the diagram below, this parameter determines the controller output for a given amount of applied throttle. The Throttle Map setting refers to the controller output at half throttle, the midpoint of the throttle's full active range (the range between Throttle 0% and Throttle 100%).</p>  <p>Setting Throttle Map at 50% provides a linear output response to throttle position. Values below 50% reduce the controller output at low throttle settings, providing enhanced slow speed control. Values above 50% give the vehicle a faster, jumpier feel at low throttle settings.</p> <p>Controller output begins when the throttle is moved beyond Throttle 0% and continues to increase—following the curve defined by the Throttle Map setting—as the throttle input increases, and reaches maximum output when the throttle input crosses the Throttle 100% threshold.</p>
Throttle 0%	0.0–2.0 V	Defines the throttle input voltage at which a throttle command begins. Voltages lower than the programmed value (but higher than the programmed Throttle Fault Lo) are interpreted to be in a 0% deadband.
Throttle 100%	2.1–5.0 V	Defines the throttle input voltage that gives a full throttle command. Input voltages above the programmed value (but lower than the programmed Throttle Fault Hi) are interpreted as 100% throttle command.
Throttle Fault Lo	0.0–2.0 V	The Throttle Fault Lo parameter sets the lower throttle fault threshold. Throttle input voltages below this programmed threshold will signal a throttle fault.

THROTTLE MENU, cont'd

PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Throttle Fault Hi	3.0–5.0 V	The Throttle Fault Hi parameter sets the upper throttle fault threshold. Throttle input voltages above this programmed threshold will signal a throttle fault.
5v Enable	On/Off	When this parameter is programmed On, Pot Hi (pin J1-4) is pure 5V and Pot Lo (pin J1-6) is ground; this is the setting to use with an electronic throttle. When this parameter is programmed Off, the Pot Hi and Pot Lo pins are current limited by internal fault-detecting resistors; this is the setting to use with resistive throttles.

WARNING OPTIONS MENU


PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Overvoltage Beep	On/Off	When this parameter is programmed On, the warning alarm will sound during overvoltage operation.
Anti-Rollback Beep	On/Off	When this parameter is programmed On, the warning alarm will sound during anti-rollback operation.

FIELD MAPS MENU: Positive Field Map		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
M1 Field Min	1–10 A	<p>Defines the minimum allowed current in the motor's field winding when the vehicle is traveling in the forward direction, operating in Mode 1. The forward Field Min setting may affect the vehicle's maximum speed and, to some extent, the smoothness with which the vehicle starts and transitions between drive and regen. If the parameter is set too high, the vehicle's top speed will be reduced and torque bumps may be evident when the vehicle is inched or changes direction.</p> <p>One of the greatest advantages of a properly set Field Min parameter is that it will prevent uncontrolled acceleration when the vehicle goes down ramps or when it is unloaded from trucks, etc.</p>
Reverse Field Min	1–10 A	<p>Defines the minimum allowed current in the motor's field winding when the vehicle is traveling in the reverse direction; this setting applies regardless of whether the vehicle is operating in Mode 1 or Mode 2.</p> <p>See the description of M1 Field Min for more information on how Field Min works.</p>
M2 Field Min	1–10 A	See M1 Field Min description; M2 Field Min applies when the vehicle is in Mode 2.
Field Map Start	0–100 A	<p>Defines the armature current at which the field current starts to increase from the programmed Field Min setting when the vehicle is traveling in the forward direction.</p> <p>Care should be taken to ensure that high Field Map Start values do not move the motor's operating characteristics outside its safe commutation area.</p>
Field Map	20–80 %	<p>Defines the shape of the field map curve. It is set as a percentage of the field current between the Field Min and Field Max values.</p> <p>As shown in the diagram on the next page, the Field Map parameter sets the field current at the armature current that is halfway between the programmed Field Map Start current and the programmed Field Map End current. This halfway point is called the Field Map Midpoint.</p> <p>With Field Map set at 50% and Field Map Start set at zero, the motor's field current increases linearly with increasing armature current—thus emulating a series wound motor. Decreasing the Field Map setting reduces the field current at a given armature current; i.e., it weakens the field. As the field current is reduced, the motor will be able to achieve higher speeds.</p> <p>Care should be taken to ensure that excessively low Field Map Start values do not move the motor's operating characteristics outside its safe commutation area.</p>
Field Max	12–30 A	Defines the maximum allowed current in the motor's field winding when the vehicle is traveling in the forward direction. The setting of this parameter will determine the motor's maximum torque during drive operation, and will limit the power dissipation in the field winding itself.
Field Map End	150–275 A*	<p>Defines the armature current at which the field map clamps to the programmed Field Max value, when the vehicle is moving in the forward direction.</p> <p>Care should be taken to ensure that high Field Map End values do not move the motor's operating characteristics outside its safe commutation area.</p> <p>Field Map End is adjustable from 150 A up to the controller's full rated current. The full rated current depends on the controller model; see Table C-1.</p>

* Note: Upper limit of range is model-specific.

FIELD MAPS MENU: Negative Field Map		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Neg Field Map Start	0–100 A	
Neg Field Map	20–80 %	These four parameters function similarly to the four corresponding parameters in the Positive Field Menu, except they apply during regen braking rather than during drive.
Neg Field Max	12–30 %	
Neg Field Map End	150–275 A*	

* Note: Upper limit of range is model-specific.



EM BRAKE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
EM Brake	On–Off	<p>This parameter is used to turn the electromagnetic (EM) brake function on or off. An EM brake keeps the vehicle from moving after it comes to rest, which can be very useful when stopping on a hill.</p> <p>This function requires appropriate hardware; see the wiring diagram (Fig. 3) on page 8.</p>
EMB Pull In %	10–100 %	<p>Defines the peak voltage momentarily applied to the EM brake. The EMB pull-in function supplies a high initial voltage for 0.1 second when the driver first turns on, to ensure proper closure.</p> <p>The parameter is programmable as a percentage of the battery voltage. The value for EMB Pull In % should be determined from specifications or advice from the relay or EMB manufacturer.</p>
EMB Holding %	10–100 %	<p>Defines the continuous voltage applied to the EM brake after the initial 0.1 s pull-in. The driver output is pulse width modulated at the programmed percentage of the battery voltage.</p> <p>Using this parameter, the average applied voltage can be reduced so that a coil that is not rated for the full battery voltage can be used. For example, a relay coil rated for 24V could be used in a 48V system if EMB Holding % is set to 35 ($48V * 0.35 = 16.8V$), as 16.8V is well above typical dropout voltage. The resulting voltage must be set high enough to hold the relay closed under all shock and vibration conditions the vehicle will be subjected to. Low settings minimize the current required to power the coil, thereby reducing coil heating and increasing battery life.</p> <p>The value for EMB Holding % should be determined with specifications or advice from the relay or EMB manufacturer.</p>
EMB Delay	0.0–5.0 s	<p>Defines a delay time before the EM brake drops. The delay countdown begins either (1) when the vehicle has come to rest and the main contactor has opened, or (2) during field braking, when the vehicle has slowed below the programmed Field Brake Speed (see Field Brake menu).</p>
EMB Speed Check	On–Off	<p>When programmed On, the EMB Speed Check function adds extra measures to prevent the locking of the EM brake at high vehicle speeds under conditions when the main contactor is open (for example, if the keyswitch is turned off during driving or a fault is detected). The controller will override the EMB Delay in an attempt to allow the vehicle to slow down before engaging the EM brake.</p>
EMB Speed Value	0–62	<p>Defines the speed at which the EM brake is permitted to lock. Although it is programmable from zero to 62, it is typically set at the extreme low end of that range. The purpose of EMB Speed Value is to prevent dropping the EM brake at high speed, which could be dangerous on certain terrain (e.g., wet grass).</p> <p>Note: The units are defined by the RPM / Speed parameter; see page 22.</p> <p>In the event of main contactor failure (or fault detection that commands the contactor to open) the EM brake parameters control the brake as follows:</p> <p><i>EMB Speed Check = Off</i> EM brake driver will turn off after EMB Delay has expired.</p> <p><i>EMB Speed Check = On</i> EM brake driver will not turn off until vehicle speed is detected as having reduced to the set EMB Speed Value. If EMB Speed Value is set below 1.0, the EM brake driver will not turn off until the vehicle reaches rest.</p>

FIELD BRAKE MENU											
PARAMETER	ALLOWABLE RANGE	DESCRIPTION									
Field Brake	On–Off	<p>This parameter is used to turn the field brake function on or off. When enabled, field braking slows the vehicle near zero speed.</p> <p>When Field Brake = On, the Field Brake Speed, Max, and Rate parameters apply; they have no effect when Field Brake = Off.</p>									
Field Brake Speed	0–6.0	<p>Defines the speed threshold below which field braking will occur, when field braking is enabled.</p> <p>Note: The units are defined by the RPM / Speed parameter; see page 22.</p> <p>When the throttle has been released and vehicle speed is detected to be below the programmed Field Brake Speed, the field current starts to increase toward the value specified by Field Brake Max at a rate specified by Field Brake Rate.</p> <p>If the Field Brake Speed threshold is set very low, field braking will occur only at the very end of the vehicle deceleration. If the vehicle does not slow to the programmed Field Brake Speed threshold (down a steep hill, for example) field braking will not occur as the threshold will not be reached.</p>									
Field Brake Max	1.0–30.0 A	<p>Defines the maximum field voltage permitted during field braking, when field braking is enabled. The field current defined by Field Brake Max overrides the standard field map current below the speed programmed for Field Brake Speed.</p> <p>In applications with an electromagnetic brake, the amount of field current set by Field Brake Max is applied for the maximum time specified by EMB Delay prior to locking the EM brake. A high value of Field Brake Max helps to ensure the vehicle uses sufficient braking to slow to a stop before locking the EM brake.</p> <p>In applications configured for WalkAway™ operation (available on 1266A models only), lower Field Brake Max values are useful in providing softer braking near zero speed. Setting the value too low may render the controller incapable of sensing vehicle rollback. However, even though the anti-rollback function may not be activated, the plug braking generated by the field current will still act to slow the vehicle.</p>									
Field Brake Rate	0–6	<p>Defines how quickly the field current rises during field braking, when field braking is enabled.</p> <p>Field Brake Rate is adjustable from 0 to 6; this index value defines the time for the field current to rise to the programmed Field Brake Max, as shown in the examples below. The higher the setting, the faster the rise. (In these examples,</p> <table border="1" data-bbox="695 1465 1240 1625"> <thead> <tr> <th>INDEX</th> <th>FIELD CURRENT RANGE</th> <th>TIME OF RISE</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0.0 – 30.0 A</td> <td>3.2 s</td> </tr> <tr> <td>6</td> <td>0.0 – 30.0 A</td> <td>0.5 s</td> </tr> </tbody> </table> <p>Field Brake Max = 30.0 A.)</p> <p>When an EM brake is used, the field current rises until it reaches the programmed Field Brake Max and maintains that current for the duration of EMB Delay, at the end of which the EM brake driver turns off, causing the brake to engage—if it has not already been applied due to the vehicle having stopped or started to roll back.</p>	INDEX	FIELD CURRENT RANGE	TIME OF RISE	1	0.0 – 30.0 A	3.2 s	6	0.0 – 30.0 A	0.5 s
INDEX	FIELD CURRENT RANGE	TIME OF RISE									
1	0.0 – 30.0 A	3.2 s									
6	0.0 – 30.0 A	0.5 s									

MAIN CONTACTOR MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Main Drop Out Time	1–1200 s	Defines a delay time before the main contactor opens after the vehicle has come to rest. If you are using an EM brake, you should set this to a low value so the brake engages quickly. In applications with no EM brake, you would set this to a higher value to allow anti-rollback.
Main Pull In %	10–100 %	<p>Defines the peak voltage momentarily applied to the main contactor. The Main Pull-In function supplies a high initial voltage for 0.1 second when the contactor is first turned on, to ensure proper closure.</p> <p>The parameter is programmable as a percentage of the battery voltage. The value for Main Pull In % should be determined from specifications or advice from the contactor manufacturer.</p>
Main Holding %	10–100 %	<p>Defines the continuous voltage applied to the main contactor after the initial 0.1 s pull-in. The driver output is pulse width modulated at the programmed percentage of the battery voltage.</p> <p>Using this parameter, the average applied voltage can be reduced so that a coil that is not rated for the full battery voltage can be used. For example, a relay coil rated for 24V could be used in a 48V system if Main Holding % is set to 35 ($48V * 0.35 = 16.8V$), as 16.8V is well above typical dropout voltage. The resulting voltage must be set high enough to hold the relay closed under all shock and vibration conditions the vehicle will be subjected to. Low settings minimize the current required to power the coil, thereby reducing coil heating and increasing battery life.</p> <p>The value for Main Holding % should be determined with specifications or advice from the contactor manufacturer.</p>

4

MONITOR MENU

Through its Monitor menu, the handheld programmer provides access to real-time data during vehicle operation. This information is helpful during diagnostics and troubleshooting, and also while adjusting the programmable parameters.

Table 4 Monitor Menus

<p>BATTERY VOLTAGE MENUp. 31</p> <ul style="list-style-type: none"> — Battery Voltage 	<p>FAULT COUNTERS</p> <ul style="list-style-type: none"> — Pot Low Fault — Pot High Fault — Throttle Fault — Low Battery Voltage — OverVoltage — Thermal Cutback — Ext. 15v Fault — HPD — EMB OverCurrent — Main Drvr OverCurrent — EM Brake Fault — EM Brake Driver Off — Main Welded — Speed Sensor Fault — Main Driver On — Main Coil Open — Main Dropout 1 — Motor Stall — Main Driver Off — Main Dropout 2 — Current Sense Fault — M- Shorted — PreCharge Fault — Field Missing — Hardware Failsafe 	<p>FAULT COUNT HOURMETERS</p> <ul style="list-style-type: none"> — Pot Low Fault Hr — Pot High Fault Hr — Throttle Fault Hr — Low Battery Voltage Hr — OverVoltage Hr — Thermal Cutback Hr — Ext. 15v Fault Hr — HPD Hr — EMB OverCurrent Hr — Main Drvr OverCurrent Hr — EM Brake Fault Hr — EM Brake Driver Off Hr — Main Welded Hr — Speed Sensor Fault Hr — Main Driver On Hr — Main Coil Open Hr — Main Dropout 1 Hr — Motor Stall Hr — Main Driver Off Hr — Main Dropout 2 Hr — Current Sense Fault Hr — M- Shorted Hr — PreCharge Fault Hr — Field Missing Hr — Hardware Failsafe Hr
<p>VEHICLE MENUp. 31</p> <ul style="list-style-type: none"> — Speed — Odometer — Hour Meter 		
<p>I/O MENUp. 31</p> <ul style="list-style-type: none"> — Throttle — Foot Input — Key Input — Forward Input — Reverse Input — Mode Input — Charger Inhibit — EM Brake Driver — Main Cont Driver 		
<p>CONTROLLER MENUp. 31</p> <ul style="list-style-type: none"> — Temperature — Boost Remaining Time — Arm Current — Field Current — Armature PWM — Field PWM 		

For descriptions of the faults, see Section 7: Diagnostics and Troubleshooting. The corresponding Fault Count Hourmeters show when the last fault occurred, based upon the internal hourmeter.

BATTERY VOLTAGE MENU

VARIABLE	UNITS	DESCRIPTION
Battery Voltage	V	Measured voltage of battery pack.

VEHICLE MENU

VARIABLE	UNITS	DESCRIPTION
Speed	mph or km/h	Speed at which the vehicle is presently traveling.
Odometer	miles or km	Vehicle travel distance since odometer was last reset.
Hour Meter	hours	Total hours of “On” time since hour meter was last reset.

I/O MENU

VARIABLE	UNITS	DESCRIPTION
Throttle	%	Throttle request, as percentage of full active throttle range.
Foot Input	[On/Off]	Status of input at pin J1-13. On = pedal is released.
Key Input	[On/Off]	Status of input at pin J1-15.
Forward Input	[On/Off]	Status of input at pin J1-12. On = Forward is selected.
Reverse Input	[On/Off]	Status of input at pin J1-11. On = Reverse is selected.
Mode Input	[On/Off]	Indicates mode the vehicle is operating in: Mode 1 or Mode 2.
Charger Inhibit	[On/Off]	Status of input at pin J1-8. On = operation is inhibited.
EM Brake Driver	[On/Off]	Status of driver at pin J1-2. On = EM brake is released.
Main Cont Driver	[On/Off]	Status of input at pin J1-7. On = voltage is applied to main contactor coil.

CONTROLLER MENU

VARIABLE	UNITS	DESCRIPTION
Temperature	°C	Controller heatsink temperature.
Boost Remaining Time	s	Seconds remaining in the programmed Boost Time.
Arm Current	A	Motor’s armature current.
Field Current	A	Motor’s field current.
Armature PWM	%	PWM of motor armature.
Field PWM	%	PWM of motor field.

5

INSTALLATION CHECKOUT

Before operating the vehicle, carefully complete the following checkout procedure. If you find a problem during the checkout, refer to the diagnostics and troubleshooting section (Section 6) for further information.



Put the vehicle up on blocks to get the drive wheels up off the ground before beginning these tests.

Do not stand, or allow anyone else to stand, directly in front of or behind the vehicle during the checkout.

Make sure the keyswitch is off, the throttle is released, and the forward and reverse switches are open.

Wear safety glasses and use well-insulated tools.

1. Connect the programmer to the programmer connector.
2. Turn the run/store switch on. The programmer should power up with an initial display. If it does not, check for continuity in the run/store switch circuit and controller ground.
3. Next, go to the Monitor » Faults menu. The display should indicate “No Known Faults.”

If there is a problem, the programmer will display a diagnostic message. When the problem has been corrected, it may be necessary to cycle the run/store switch in order to clear the fault.
4. Turn the keyswitch on, select a direction, and operate the throttle. The motor should begin to turn in the selected direction. If it turns in the wrong direction, first verify the wiring to the forward and reverse switches. If the wiring is correct, turn off the controller, disconnect the battery, and exchange the motor’s field connections (**S1** and **S2**) on the controller. The motor should now turn in the proper direction. The motor should run proportionally faster with increasing throttle. If not, refer to Section 6.

5. Next, go to the Monitor » I/O menu. Scroll down to observe the status of the switches:
 - Foot Input (pedal switch)
 - Key Input
 - Forward Input
 - Reverse Input
 - Mode Input
 - Charger InhibitCycle each switch in turn, observing the programmer. The programmer should display the correct status for each switch.
6. Take the vehicle down off the blocks and drive it in a clear area. It should have smooth acceleration and good top speed. Recommended procedures for tuning the vehicle's driving characteristics are presented in Section 5: Tuning Guide.
7. Test the deceleration and braking of the vehicle.
8. Disconnect the programmer when you have completed the checkout procedure, to minimize battery discharge.

6

TUNING GUIDE

The 1266A/R controller is a very powerful vehicle control system. Its wide variety of adjustable parameters allow many aspects of vehicle performance to be optimized. This section provides explanations of what the major tuning parameters do and instructions on how to use these parameters to optimize the performance of your vehicle. Once a vehicle/motor/controller combination has been tuned, the parameter values can be made standard for that system or vehicle model. Any changes in the motor, the vehicle drive system, or the controller will require that the system be tuned again to provide optimum performance.

The tuning procedures should be conducted in the sequence given, because successive steps build upon the ones before. The tuning procedures instruct personnel how to adjust various programmable parameters to accomplish specific performance goals. It is important that the effect of these programmable parameters be understood in order to take full advantage of the 1266A/R controller's powerful features. Please refer to the descriptions of the applicable parameters in Section 3 if there is any question about what any of them do.

Note: in this section, parameter names are written in ALL CAPS.

MAJOR TUNING

Five major performance characteristics are usually tuned on a vehicle:

- ① Tuning the Active Throttle Range
- ② Calibrating the Controller Speed Measurement
- ③ Tuning the Controller to the Motor (Field Mapping)
- ④ Equalizing Loaded/Unloaded Vehicle Speed on Flat Ground
- ⑤ Confirming Loaded Vehicle Speed on Downhill Grade.

These five characteristics should be tuned in the order listed.

① Tuning the Active Throttle Range

Before attempting to optimize any specific vehicle performance characteristics, it is important to ensure that the controller input is operating over its full range. To do this, the throttle should be tuned using the handheld programmer and a voltmeter. The procedures that follow will establish zero throttle, full throttle, and throttle fault parameter values that correspond to the absolute full range of your particular throttle mechanism. Note: These parameters are expressed in absolute voltages between 0.0 and 5.0 volts.

It is advisable to provide some buffer around the absolute full range of the throttle mechanism to allow for throttle resistance variations over time and temperature as well as variations in the tolerance of potentiometer values between individual throttle mechanisms. This will form areas at the top and bottom of the throttle movement range that the controller reads as 0% and 100%.

-
- STEP 1. Jack the vehicle wheels up off the ground so that they spin freely. Note: Most of the throttle tuning can be done without driving the motor, but it is advisable to check that the throttle range is still fully active when motor currents are being produced.
- STEP 2. Plug the programmer into the controller and turn on the controller with the run/store switch.
- STEP 3. Using the programmer's Program » Throttle menu, initially set the THROTTLE MAP parameter to 50%. This will provide a linear relationship between the throttle input voltage and the Throttle % displayed in the Monitor » I/O menu.
- STEP 4. Select the Monitor » I/O menu. Throttle % is the first variable in this submenu. You will need to reference the value displayed here.
- STEP 5. Use a voltmeter and test clip to measure the throttle input voltage at pin J1-5.
- STEP 6. Measure and note the voltage when the throttle is fully released.
- STEP 7. If the pedal switch is wired into the mechanical throttle mechanism, scroll down the Monitor » I/O menu to Foot Input. The display should indicate that the pedal switch is Off. Slowly apply throttle until the display indicates that the pedal switch is On. Measure the throttle voltage that is being produced at this threshold, and make a note of this value.
- STEP 8. Measure the voltage when the throttle is fully depressed, and make a note of this value.
- STEP 9. Return to the Program » Throttle menu.
Set THROTTLE FAULT LO lower than the fully released voltage measured in Step 6.
If the pedal switch is wired into the throttle mechanism, set THROTTLE 0% close to the voltage measured in Step 7. (Setting THROTTLE 0% too far below this voltage will result in loss of low-end throttle range.) If the pedal switch is **not** part of the throttle assembly, set THROTTLE 0% above the fully released voltage measured in Step 6.
Set THROTTLE 100% lower than the fully depressed voltage measured in Step 8. Set the THROTTLE FAULT HI parameter above the fully depressed voltage (but no higher than 4.7 V).
- STEP 10. Apply the keyswitch and forward switch and depress the throttle slowly through the full range of motion, causing the wheels to spin. Ensure that the Throttle % reaches 100% when the pedal is fully depressed. Ensure that the Throttle % returns to 0% when the throttle is released and that no throttle fault appears in the Faults menu.
- STEP 11. Refer to Section 3, page 23, and set the THROTTLE MAP parameter for desired performance.

② Calibrating the Controller Speed Measurement to the Vehicle

The MOTOR RPM / VEHICLE SPEED parameter is a conversion factor used to generate a vehicle speed estimate from the speed sensor input (motor RPM signal). This conversion factor allows the vehicle to be configured for various gear ratios and tire sizes. It can also be used to convert the displayed vehicle speed values (in the Program and Monitor menus) between English and metric units. Use the equations below to calculate the correct value for this parameter.

$$\text{For English units (mph): } \frac{336 \times \text{gear ratio}}{\text{tire diameter (inches)}}$$

$$\text{For metric units (km/h): } \frac{530 \times \text{gear ratio}}{\text{tire diameter (cm)}}$$

- STEP 1. Using the Program » Vehicle-Motor menu, set MOTOR RPM / VEHICLE SPEED to the correct value for the vehicle tire size and gear ratio.
- STEP 2. Set TACHO POLES to the number of poles in the motor's speed sensor (typically 8).
- STEP 3. Using the Program » Mode 1, Reverse, and Mode 2 menus, set the M1 FWD SPEED, M2 FWD SPEED and REVERSE SPEED to the desired top vehicle speeds (in either mph or km/h).

③ Tuning the Controller to the Motor

The 1266A/R controller has the flexibility to be tuned to nearly any separately excited motor from any manufacturer. The programmable parameters allow full control of the motor's maximum armature current during driving and braking. They also allow full control of the motor's maximum and minimum field current as well as the field current relationship to the armature current. This flexibility allows motor performance to be maximized while protecting it from operating outside its safe commutation region.

In order to properly tune the controller, the following information should be obtained from the motor manufacturer:

- Maximum Armature Current Rating
- Maximum Field Current Rating
- Minimum Field Current Rating
- Field Resistance (hot and cold)
- Positive and Negative Field Maps.

The performance of a separately excited motor changes depending on temperature. This is due to the change in field winding resistance as the motor heats up through use. When the field winding temperature increases, so does its resistance and therefore the maximum current that can be forced through

the winding is reduced. Reductions in the field current over the motor's typical operating temperature range can be 10% to 50%. Since the maximum available field current determines the maximum torque that can be produced by the motor, the vehicle's performance under load and up inclines will change as the motor heats up. The change in performance can be limited by tuning the motor when it is hot rather than cold. We therefore recommend that this procedure be performed with a hot motor.

- STEP 1. Using the programmer's Program » Current Limits menu, set the drive current limits (M1 MAIN C/L, M2 MAIN C/L) to the smaller of: (a) the motor's peak armature current rating, or (b) the maximum controller drive current limit. This value can later be adjusted to establish the desired vehicle driving feel in each mode.
- STEP 2. Set the REGEN C/L to the smaller of: (a) the maximum motor armature current rating, or (b) the maximum controller braking current limit. This value can later be adjusted to establish the desired vehicle braking feel (see Fine Tuning).
- STEP 3. To set FIELD MAX, first decide whether you want to maintain consistent vehicle operation throughout the motor's temperature range. If you do, proceed to Step 4. If, however, maintaining operational consistency across motor temperature is **not** a concern and achieving maximum torque **is**, skip to Step 5.
- STEP 4. For the most consistent operation across temperature, set the FIELD MAX (Program » Field Mapping » Positive Field Maps) to the maximum field current available at low battery voltage with a hot motor. To determine this current, divide the **low battery voltage** (typically 70% of nominal) by the **high temperature** field winding resistance specification provided by the manufacturer. Set FIELD MAX to this value. This will provide good consistency between motor performance in both hot and cold states. Skip to Step 6.
- STEP 5. For the maximum torque regardless of temperature, set FIELD MAX to the motor's rated absolute maximum field current. To determine the absolute maximum field current, divide the **nominal battery voltage** by the **low temperature** field winding resistance specification provided by the manufacturer. Set FIELD MAX to this value. This will provide the maximum possible torque under all conditions.

This has now set the FIELD MAX parameter.


The next step is to set the FIELD MIN parameter. **FIELD MIN should never be set below the rated value specified by the manufacturer.** Operating the motor at lower field currents than specified will result in operation outside the motor's safe commutation region and will cause arcing between the brushes and commutator, significantly reducing motor and brush life.

- STEP 6. Set NEG FIELD MAX (Program » Field Mapping » Negative Field Maps) at or below the FIELD MAX setting.

If the controller is tuned such that the system is operating outside the motor's safe commutation region, there will be audible and visual indications. Under normal operation, the motor will emit a whine with a pitch that increases with increasing rotation speed. If a “scratchy” sound is also heard, this is usually an indication that pin arcing is occurring in the motor and it is operating outside its safe commutation region. This operation is normally accompanied by a strong smell from the motor. If the brushes and commutator bars are visible, arcing may be seen.

The further outside the safe commutation region the motor is operating, the worse the arcing will be. **Operation outside the safe commutation region is very detrimental to the motor.** The FIELD MIN and possibly also the FIELD RAMP should be increased until the indications of arcing stop. Decreasing FIELD MAP START will also help to move operation back into the safe commutation region.

The typical default field map settings are as follows.



Further tuning of the field maps is described in procedures ⑤, ⑦, and ⑨.

④ Equalizing the Loaded/Unloaded Vehicle Top Speed on Flat Ground

The controller and vehicle should be configured as follows prior to setting the maximum vehicle speed:

- M1 MAIN C/L and M2 MAIN C/L as established in tuning procedure ③
- FIELD MAP (positive) = 50%
- FLD MAP START (positive) = 20% of the specified drive current limit
- M1 FIELD MIN and M2 FIELD MIN = manufacturer's specified minimum or 3 A
- The vehicle can be loaded or loaded

If full closed loop speed control is required in both loaded and unloaded operation, conduct this procedure with the vehicle loaded.

- The vehicle battery should be fully charged.

Drive the vehicle on a flat surface in a clear area during this procedure. Precautions should be taken to ensure safety of test personnel and anyone in the test area.

STEP 1. In the Program » Mode 1 menu select the M1 MAX SPEED parameter and set it to the desired top forward speed for Mode 1. Confirm that Mode 1 is selected by reading the Mode Input value in the Monitor menu.

STEP 2. Turn on the keyswitch and the Forward switch and apply full throttle. While driving the vehicle with full throttle applied, observe the Speed and Armature PWM readings in the Monitor menu (Monitor » Vehicle » Speed and Monitor » Controller » Armature PWM). (Note: Speed will display as 0.8 for speeds below 1.0.)

If the speed is being limited by the field map parameters, the Armature PWM will be 100%. In this case, skip to Step 4.

If the vehicle is truly in closed loop speed control, the Armature PWM will be less than 100%. The controller will be limiting the vehicle speed to the programmed maximum speed by reducing the applied armature voltage below the value commanded by the throttle. In this case, proceed to Step 3.

STEP 3. Observe the Armature PWM and Armature Current readings while driving at top speed. Set the FIELD MAP START to a value above the Armature Current reading. With the vehicle unloaded, increase the M1 FIELD MIN until the Armature PWM is between 60–70%. When the vehicle is loaded the controller will output a higher value of Armature PWM to achieve this speed.

For slow speeds, a higher FIELD MIN is preferable, in order to ensure a smooth transition between the drive and regen states. For high speeds, a lower FIELD MIN is usually necessary to allow the vehicle to achieve true closed loop speed control and not be limited by the field current. Skip to Step 5.

STEP 4. In this case, the vehicle's top speed is being limited by the field mapping parameters. Observe the Armature Current in the Monitor menu, and set the FIELD MAP START to a value above the Armature Current reading. Reduce the M1 FIELD MIN until the Speed input (Monitor » Vehicle » Speed) shows the programmed maximum speed (i.e., the speed set by M1 MAX SPEED) and the Armature PWM reading drops below 100%, indicating that the controller is in closed loop speed control. When the vehicle is unloaded the controller will output a lower value of Armature PWM to maintain this speed.

Do not set the field mapping parameters outside the motor's safe commutation limits.

STEP 5. Repeat from Step 1 for the Mode 2 forward speed and for reverse speed. Separate field minimum parameters are provided for all three speeds (M1, M2, REVERSE).

⑤ Confirming Loaded Vehicle Speed on Downhill Grade

STEP 1. Set the following parameters:

- REGEN C/L = maximum specified by the motor specs
- NEG FIELD MAP END = at or below REGEN C/L
- NEG FIELD MAX = FIELD MAX (as set in procedure ③, step 6)
- M1 BRAKE END = at least 1–2 mph or km/h below M1 MAX SPEED
- M1 BRAKE MAX = 100%.

STEP 2. With the vehicle fully loaded, drive down the steepest required grade. Observe the Arm Current displayed in the Monitor menu (it will be a negative value). This value is the regen current required to prevent exceeding the programmed top speed. It is an important value to be aware of when adjusting the brake mapping parameters for optimum compression braking feel.

If the vehicle top speed is exceeded, increase the NEG FIELD MAX and NEG FLD RAMP or decrease NEG FLD MAP EN to help provide additional braking torque earlier.

See brake mapping examples on page 41.

STEP 3. Repeat the procedure for the Mode 2 forward speed and for reverse speed. Separate brake mapping parameters are provided for each speed (M1, M2, REVERSE).

FINE TUNING

Seven additional vehicle performance characteristics can be adjusted:

- ⑥ Response to Increased Throttle
- ⑦ Response to Full Throttle Release (Compression Braking)
- ⑧ Transitioning from Flat Ground to Downhill
- ⑨ Hill Climbing
- ⑩ WalkAway™ Braking
- ⑪ Low-Speed Field Braking
- ⑫ Applying the EM Brake.

These characteristics are related to the “feel” of the vehicle and will be different for various applications. Once the fine tuning has been accomplished, it should not have to be repeated on every vehicle.

⑥ Response to Increased Throttle

The vehicle’s response to throttle increases can be modified using the ACCEL, THROTTLE MAP, and FIELD MAX parameters. Optimal vehicle response is tuned by adjusting these parameters and then accelerating the vehicle from a dead stop under various throttle transition conditions.

- STEP 1. Set THROTTLE MAP as desired. In most applications a setting below 50% is used to provide greater control for low-speed maneuvering.
- STEP 2. Select Mode 1. While driving the vehicle, adjust M1 ACCEL for the best overall acceleration response. If the vehicle starts too slowly under all driving conditions, M1 ACCEL should be reduced. (Remember, the accel rate parameter is in units of time.)
- STEP 3. *Increasing vehicle acceleration.* If acceleration feels good for slow or moderate throttle transitions but the vehicle initially starts too slowly, set FIELD MAX higher. If acceleration is not satisfactory when the throttle is transitioned quickly from zero to full speed, decrease M1 ACCEL to obtain the desired fast throttle response.
- STEP 4. *Achieving better control at low speeds.* If the vehicle responds well for fast, full range throttle transitions but is too jumpy during low speed maneuvering, reduce the THROTTLE MAP.
- STEP 5. Select Mode 2 and repeat the procedure.

You may wish to dedicate one of the two modes for precision maneuvering. The ACCEL, MAX SPEED, and MAIN C/L parameters can be tuned exclusively for this precision-maneuvering mode to obtain comfortable vehicle response. Because THROTTLE MAP and FIELD MAX are not mode-specific, you may need to re-tune Mode 1 if you make adjustments to these two parameters when tuning Mode 2.

⑦ Response to Full Throttle Release (Compression Braking)

The way the vehicle responds when the throttle is completely released can be modified using the DECEL, REGEN C/L, brake mapping, and negative field mapping parameters. Braking parameters should be set for M1 and M2 forward speeds and for reverse speed.

When the throttle is released, the DECEL rate acts to drive the armature PWM down to zero, but the BRAKE MAP will ensure that the braking (regen) current is limited to the value for the present vehicle speed. This allows a profile to be specified that allows high initial braking torque, softening to a milder torque as the vehicle slows down. Alternatively, you can set up a profile with strong braking down to zero speed. A lower DECEL value will also provide a more immediate strong braking feel.

- STEP 1. Set the brake mapping parameters to the default values shown in Example A on the next page.

Note: With the default settings, maximum braking torque is specified at top speed, tailing off to a much milder torque at low speeds.

- STEP 2. Drive the vehicle at full speed on flat ground and release the throttle, paying attention to the feel of vehicle braking. If the initial braking is too sudden, increase the DECEL value. If the initial braking is too strong, lower the BRAKE MAX or increase the BRAKE END.

When setting a very mild compression braking feel, beware of setting the BRAKE MAX and REGEN C/L to values that will inhibit the controller's ability to maintain top speed braking—in both throttle applied and throttle released conditions—on a downhill grade.


If the braking torque remains too strong after the vehicle has been brought to a slower speed, reduce the BRAKE MAP and BRAKE MIN parameters, and increase the BRAKE START. These adjustments will act to limit the braking torque at the lower speeds.

If, on the other hand, you want to *increase* braking torque at lower speeds, increase the BRAKE MAP or BRAKE MIN parameters, or reduce the BRAKE START.

Note: The setting of the brake mapping and DECEL parameters will also affect the feel of the vehicle deceleration during partial throttle releases. After completing procedure ⑦ for full throttle release, make sure the deceleration during partial throttle release is acceptable.

Example A: GENERIC DEFAULT BRAKE MAP


This map has strong high-speed braking torque, and mild low-speed braking torque.



REGEN C/L	200 A
M1 MAX SPEED	16 mph
M1 BRAKE MIN	10 % (20 A)
M1 BRAKE MAX	100 % (200 A)
M1 BRAKE START	5 mph
M1 BRAKE END	14 mph
M1 BRAKE MAP	22 % (60 A)

Example B


This map has strong braking to vehicle rest.



REGEN C/L	200 A
M1 MAX SPEED	10 mph
M1 BRAKE MIN	40 % (80 A)
M1 BRAKE MAX	100 % (200 A)
M1 BRAKE START	4 mph
M1 BRAKE END	7 mph
M1 BRAKE MAP	50 % (140 A)

Example C

This map has mild top-speed braking.



REGEN C/L	160 A
M1 MAX SPEED	16 mph
M1 BRAKE MIN	15 % (24 A)
M1 BRAKE MAX	100 % (160 A)
M1 BRAKE START	14 mph
M1 BRAKE END	18 mph
M1 BRAKE MAP	50 % (92 A)

Note: BRAKE MIN and BRAKE MAX are percentages of REGEN C/L.
BRAKE MAP is a percentage of the range between BRAKE MIN and BRAKE MAX.

⑧ Transitioning from Flat Ground to Downhill

To ensure smoothness on transitions from positive drive current to negative regen current, set the NEG FIELD MAP START greater than zero to provide a constant value of field current as the motor transitions between drive and regen braking.

If speed “hunting” or oscillation occurs on downhill grades, reduce the NEG FIELD MAX and NEG FIELD MAP parameters or increase the NEG FIELD MAP END parameter to ensure an initially shallower negative field map profile.

Note: The “negative field map” refers to the field and armature (regen braking) current relationship regardless of forward or reverse direction.

⑨ Hill Climbing

The vehicle response to increased gradients such as hills and loading ramps can be tuned via the FIELD MAP parameter. Decreasing the FIELD MAP value allows faster vehicle speeds while climbing, but it will also have the effect of reducing the ability of the controller to generate torque in the vehicle’s mid range speeds.

STEP 1. If faster vehicle speed is desired when climbing ramps, decrease FIELD MAP until the desired ramp climbing speed is attained. It should be noted that if the motor’s torque capability is exceeded under the conditions of load and ramp gradient, vehicle speed will be limited by the motor’s capability and the desired vehicle speed may not be attainable. The system will find a compromise point at which sufficient motor torque is generated to climb the ramp at an acceptable speed. If FIELD MAP is reduced to 20% and the desired speed is still not attained, the system is being limited by the motor’s torque capability under these conditions.

Caution should be used in reducing FIELD MAP since at low FIELD MAP values it is possible that the motor could be operated outside its safe commutation region.

STEP 2. If the drive system cannot produce sufficient torque for a fully loaded vehicle to climb the desired ramp, try increasing the FIELD MAP, FIELD MAX, and/or MAIN C/L. The impact of increasing these values on other driving characteristics must be evaluated. Increasing the FIELD MAX will provide more field current, and increasing the MAIN C/L will provide more armature current. If FIELD MAX is set at the manufacturer’s specified limit and the MAIN C/L is set at the rated maximum, then vehicle speed up the ramp is limited by the motor or the vehicle’s gearing and cannot be increased by tuning the controller.

Note: To determine whether the controller’s armature current is at its set value during ramp climbing, read the Arm Current in the Monitor » Controller menu.

⑩ WalkAway™ Braking

All 1266A controllers have the WalkAway™ function; WalkAway™ braking will occur whenever vehicle movement is detected while the main contactor is open. In general this is used to prevent uncontrolled vehicle rolling after the vehicle has reached rest. It also is used to slow the vehicle if it is rolling when the keyswitch is turned off or in certain fault conditions that cause the main contactor to open.

The strength of the WalkAway™ braking is controlled by the WALKAWAY C/L and PLUG C/L parameters.

STEP 1. Drive the vehicle onto a steep grade, and hold it with the foot brake until you hear the main contactor open.

STEP 2. Release the foot brake. The vehicle will begin to roll at a slow pace, followed by WalkAway™ braking (indicated by a beeping tone).

If the vehicle is rolling too fast, increase the WALKAWAY C/L and/or the PLUG C/L.

STEP 3. Check that these braking parameter adjustments do not make the braking feel too abrupt on milder slopes.

⑪ Low-Speed Field Braking

The FIELD BRAKE parameter provides an additional mechanism for slowing the vehicle down at slow speeds. There are three uses for field braking:

- a. Providing extra braking torque as the vehicle slows to a stop.
- b. Strengthening the anti-rollback braking in vehicles that do not have an EM brake.

Note: The anti-rollback function can never hold a vehicle perfectly stationary on an incline and is not intended to replace a mechanical or electromagnetic brake for this purpose. However, it will prevent uncontrolled vehicle coasting in this situation.

- c. On vehicles equipped with an EM brake, field braking and the EM brake can be used together to stop the vehicle and to prevent the vehicle from rolling back down a hill.

Note: This use of field braking is covered separately in Procedure ⑫.

This procedure tunes the field braking parameters to provide additional braking at low speeds in situations (a) and (b).

STEP 1. Set the following parameters:

- FIELD BRAKE = On
- FIELD BRAKE MAX = FIELD MIN
- FIELD BRAKE SPEED = a low value (e.g., 3 mph)
- FIELD BRAKE RATE = 2.

STEP 2. Drive the vehicle up a grade.

STEP 3. Release the throttle. The vehicle will slow down and then roll back down the hill under gravity. The warning alarm will beep.

If the vehicle is rolling too fast, increase the FIELD BRAKE MAX setting. This will cause a higher plug braking current. It will also increase the braking feel as the vehicle initially slows down before changing direction.

To make the low-speed braking occur earlier, increase the FIELD BRAKE SPEED.

To increase the strength of the low-speed braking as the vehicle is brought to a stop, increase the FIELD BRAKE RATE and FIELD BRAKE MAX.

STEP 4. Drive the vehicle on flat ground to confirm that the extra braking feel provided by these adjustments is acceptable.

⑫ EM Brake Operation (with optional EM brake)

During normal operation, the EM brake is applied at the expiration of the EMB DELAY. The FIELD BRAKE setting (Off or On) determines when the EMB DELAY countdown begins.

Note: For EM brake control during fault conditions, see EMB SPEED VALUE, page 27.

Note: For the vehicle to be towable, the OEM must provide a means to release the EM brake.

⑫-a FIELD BRAKE = Off

Here the EMB DELAY sets the length of time between the main contactor opening and the EM brake being applied. The EM brake will not be applied until the main contactor has opened.

STEP 1. Set the following parameters:

- FIELD BRAKE = Off
- EMB DELAY = <1.0 second
- MAIN DROP OUT TIME = 1.0 – 2.0 seconds.

⑫-b FIELD BRAKE = On

Here the EMB DELAY sets the length of time the field current is held at the FIELD BRAKE MAX before the EM brake is applied. This guarantees that the EM brake will be applied some time after the vehicle has slowed below the FIELD BRAKE SPEED (even though the main contactor may still be closed) and is useful in preventing the vehicle from continuing to roll forward. Additionally, if the controller detects that the vehicle has reached rest, or is starting to roll back, the EM brake will be applied immediately to prevent further vehicle movement.

STEP 1. Set the following parameters:

- FIELD BRAKE = On
- EMB DELAY = a low value (e.g., 3 seconds)
- FIELD BRAKE MAX = FIELD MIN, or higher
- FIELD BRAKE RATE = a low value (e.g., 2).

STEP 2. Drive up a hill and release the throttle. The vehicle should slow to a stop and the EM brake should drop just as the vehicle begins to roll backwards. If the vehicle rolls backwards excessively, increase the FIELD BRAKE MAX.

STEP 3. Drive down a mild slope and release the throttle. The vehicle will slow down but may not reach a complete stop depending on the gradient of the slope. You should feel the field braking torque, followed by the EM brake being applied. If the EM brake is applied too early, increase the FIELD BRAKE MAX and the EMB DELAY.

STEP 4. After adjusting these parameters, drive the vehicle on flat ground to confirm that the EM brake timing is acceptable. To avoid unnecessarily abrupt stops, the parameters should be set so that when driving on flat ground the vehicle reaches rest before the EM brake is applied.

7

DIAGNOSTICS AND TROUBLESHOOTING

The 1266A/R controller provides diagnostics information to assist technicians in troubleshooting drive system problems. This information is displayed on the handheld programmer (or PC Programming Station). Refer to the troubleshooting chart for suggestions covering a wide range of possible faults.

The programmer presents complete diagnostic information in plain language. Faults are displayed in the Monitor » Faults menu, and the status of the controller inputs/outputs is displayed in the Monitor » I/O menu.

Accessing the Fault History menu provides a list of the faults that have occurred since the fault history file was last cleared. Checking (and clearing) the fault history file is recommended each time the vehicle is brought in for maintenance; clearing the fault history file also clears the fault counters.

The following 4-step process is recommended for diagnosing and troubleshooting an inoperative vehicle: (1) visually inspect the vehicle for obvious problems; (2) diagnose the problem, using the programmer; (3) test the circuitry with the programmer; and (4) correct the problem. Repeat the last three steps as necessary until the vehicle is operational.

Example: A vehicle that does not operate in “forward” is brought in for repair.

STEP 1: Examine the vehicle and its wiring for any obvious problems, such as broken wires or loose connections.

STEP 2: Connect the programmer, select the Monitor » Faults menu, and read the displayed fault information. In this example, the display shows “No Known Faults,” indicating that the controller has not detected any problems.

STEP 3: Select the Monitor » I/O menu, and observe the status of the inputs and outputs in the forward direction. In this example, the display shows that the forward switch did not close when “forward” was selected, which means the problem is either in the forward switch or the switch wiring.

STEP 4: Check or replace the forward switch and wiring and repeat the test. If the programmer shows the forward switch closing and the vehicle now drives normally, the problem has been corrected.

TROUBLESHOOTING CHART

PROGRAMMER LCD DISPLAY	EXPLANATION	POSSIBLE CAUSE
Current Sense Fault	Armature or field current sensor sensor fault.	1. Controller defective.
EM Brake Driver Off	EM brake driver held high.	1. EM brake coil shorted.
EM Brake Fault	Missing brake coil.	1. EM brake coil open or not connected. 2. Breaker/fuse tripped or open. 3. Breaker/fuse defective.
EM Brake OverCurrent	EM brake driver overcurrent.	1. EM brake output shorted to ground.
Ext. 15v Fault	15V supply line has been pulled below 12V.	1. Short to ground in speed sensor.
Field Missing	Field winding fault.	1. Motor field wiring loose. 2. Motor field wiring open.
HW Failsafe	Self-test or watchdog fault.	1. Controller defective.
HPD	High Pedal Disable fault.	1. Improper sequence of direction and throttle inputs.
Low Battery Voltage	Low battery voltage.	1. Battery voltage < undervoltage cutback threshold. 2. Corroded battery terminal. 3. Loose battery or controller terminal.
M- Shorted	Internal M- short to B-.	1. Incorrect power wiring. 2. Controller defective.
Main Coil Open	Missing main contactor.	1. Main contactor coil open or not connected.
Main Driver Off	Main contactor driver held high.	1. Main contactor coil shorted.
Main Driver On	Main contactor coil held low.	1. Main contactor missing or wire to coil open.
Main Driver OverCurrent	Main contactor driver overcurrent.	1. Contactor coil shorted.
Main Dropout 1	Main contactor opened during drive (positive current) operation.	1. Main contactor defective.
Main Dropout 2	Main contactor opened during regen (negative current) operation.	1. Main contactor defective.
Main Welded	Main contactor welded.	1. Main contactor stuck closed. 2. Main contactor driver shorted.
Motor Stall	Motor stall at current.	1. Slope too steep for vehicle weight. 2. Mechanically locked motor. 3. EM brake wiring failure. 4. Speed sensor defective.
OverVoltage	Overvoltage.	1. Battery voltage > overvoltage shutdown threshold. 2. Vehicle operating with charger attached. 3. Battery disconnected during regen braking.
Pot High Fault	Pot High (pin J1-4) detected < 3.9 V.	1. Throttle pot resistance too low (should be $\geq 5k\Omega$). 2. External throttle circuit defective.
Pot Low Fault	Pot Low (pin J1-6) detected > 0.7 V.	1. Throttle pot resistance too low (should be $\geq 5k\Omega$). 2. External throttle circuit defective.

TROUBLESHOOTING CHART, cont'd

PROGRAMMER LCD DISPLAY	EXPLANATION	POSSIBLE CAUSE
PreCharge Fault	Internal voltage too low at startup.	<ol style="list-style-type: none"> 1. External precharge resistor missing. 2. External short, or leakage path to B- on external B+ connection.
Speed Sensor Fault	No pulses from sensor.	<ol style="list-style-type: none"> 1. Speed sensor not connected. 2. Speed sensor defective.
Thermal Cutback	Over-/under-temperature cutback.	<ol style="list-style-type: none"> 1. Temperature > 85°C or < -25°C. 2. Excessive load on vehicle. 3. Improper mounting of controller. 4. Operation in extreme environments.
Throttle Fault	Wiper signal out of range	<ol style="list-style-type: none"> 1. Throttle input wire open. 2. Throttle input wire shorted to B+ or B-. 3. Throttle pot defective.

8

MAINTENANCE

There are no user serviceable parts in the Curtis 1266 A/R controller. **No attempt should be made to open, repair, or otherwise modify the controller.** Doing so may damage the controller and will void the warranty.

It is recommended that the controller be kept **clean and dry** and that its diagnostics history file be checked and cleared periodically.

CLEANING

Periodically cleaning the controller exterior will help protect it against corrosion and possible electrical control problems created by dirt, grime, and chemicals that are part of the operating environment and that normally exist in battery powered systems. **When working around any battery powered vehicle, proper safety precautions should be taken.** These include, but are not limited to: proper training, wearing eye protection, and avoiding loose clothing and jewelry.



Use the following cleaning procedure for routine maintenance. Never use a high pressure washer to clean the controller.

1. Remove power by disconnecting the battery.
2. Discharge the capacitors in the controller by connecting a load (such as a contactor coil or a horn) across the controller's B+ and B- terminals.
3. Remove any dirt or corrosion from the power and signal connector areas. The controller should be wiped clean with a moist rag. Dry it before reconnecting the battery.
4. Make sure the connections are tight. Refer to Section 2, page 7, for maximum tightening torque specifications for the battery and motor connections.

FAULT HISTORY

The programmer's Faults menu can be used to access the controller's fault history file. The programmer will read out all the faults that the controller has experienced since the last time the fault history file was cleared. The faults may be intermittent faults, faults caused by loose wires, or faults caused by operator errors. Faults such as contactor faults may be the result of loose wires; contactor wiring should be carefully checked. Faults such as HPD or overtemperature may be caused by operator habits or by overloading.

After a problem has been diagnosed and corrected, it is a good idea to clear the fault history file, which also clears the fault counters. This allows the controller to accumulate a new file of faults. By checking the new fault history file at a later date, you can readily determine whether the problem was indeed fixed.

APPENDIX A

VEHICLE DESIGN CONSIDERATIONS REGARDING ELECTROMAGNETIC COMPATIBILITY (EMC) AND ELECTROSTATIC DISCHARGE (ESD)

ELECTROMAGNETIC COMPATIBILITY (EMC)

Electromagnetic compatibility (EMC) encompasses two areas: emissions and immunity. *Emissions* are radio frequency (RF) energy generated by a product. This energy has the potential to interfere with communications systems such as radio, television, cellular phones, dispatching, aircraft, etc. *Immunity* is the ability of a product to operate normally in the presence of RF energy.

EMC is ultimately a system design issue. Part of the EMC performance is designed into or inherent in each component; another part is designed into or inherent in end product characteristics such as shielding, wiring, and layout; and, finally, a portion is a function of the interactions between all these parts. The design techniques presented below can enhance EMC performance in products that use Curtis motor controllers.

Emissions

Signals with high frequency content can produce significant emissions if connected to a large enough radiating area (created by long wires spaced far apart). Contactor drivers and the motor drive output from Curtis controllers can contribute to RF emissions. Both types of output are pulse width modulated square waves with fast rise and fall times that are rich in harmonics. (Note: contactor drivers that are not modulated will not contribute to emissions.) The impact of these switching waveforms can be minimized by making the wires from the controller to the contactor or motor as short as possible and by placing the wires near each other (bundle contactor wires with Coil Return; bundle motor wires separately).

For applications requiring very low emissions, the solution may involve enclosing the controller, interconnect wires, contactors, and motor together in one shielded box. Emissions can also couple to battery supply leads and throttle circuit wires outside the box, so ferrite beads near the controller may also be required on these unshielded wires in some applications. It is best to keep the noisy signals as far as possible from sensitive wires.

Immunity

Immunity to radiated electric fields can be improved either by reducing overall circuit sensitivity or by keeping undesired signals away from this circuitry. The controller circuitry itself cannot be made less sensitive, since it must accurately detect and process low level signals from sensors such as the throttle potentiometer. Thus immunity is generally achieved by preventing the external RF energy from coupling into sensitive circuitry. This RF energy can get into the controller circuitry via conducted paths and radiated paths.

Conducted paths are created by the wires connected to the controller. These wires act as antennas and the amount of RF energy coupled into them is generally proportional to their length. The RF voltages and currents induced in each wire are applied to the controller pin to which the wire is connected. Curtis controllers include bypass capacitors on the printed circuit board's throttle wires to reduce the impact of this RF energy on the internal circuitry. In some applications, additional filtering in the form of ferrite beads may also be required on various wires to achieve desired performance levels.

Radiated paths are created when the controller circuitry is immersed in an external field. This coupling can be reduced by placing the controller as far as possible from the noise source or by enclosing the controller in a metal box. Some Curtis controllers are enclosed by a heatsink that also provides shielding around the controller circuitry, while others are partially shielded or unshielded. In some applications, the vehicle designer will need to mount the controller within a shielded box on the end product. The box can be constructed of just about any metal, although steel and aluminum are most commonly used.

Most coated plastics do not provide good shielding because the coatings are not true metals, but rather a mixture of small metal particles in a non-conductive binder. These relatively isolated particles may appear to be good based on a dc resistance measurement but do not provide adequate electron mobility to yield good shielding effectiveness. Electroless plating of plastic will yield a true metal and can thus be effective as an RF shield, but it is usually more expensive than the coatings.

A contiguous metal enclosure without any holes or seams, known as a Faraday cage, provides the best shielding for the given material and frequency. When a hole or holes are added, RF currents flowing on the outside surface of the shield must take a longer path to get around the hole than if the surface was contiguous. As more "bending" is required of these currents, more energy is coupled to the inside surface, and thus the shielding effectiveness is reduced. The reduction in shielding is a function of the longest linear dimension of a hole rather than the area. This concept is often applied where ventilation is necessary, in which case many small holes are preferable to a few larger ones.

Applying this same concept to seams or joints between adjacent pieces or segments of a shielded enclosure, it is important to minimize the open length of these seams. Seam length is the distance between points where good ohmic contact is made. This contact can be provided by solder, welds, or pressure contact. If pressure contact is used, attention must be paid to the corrosion characteristics of the shield material and any corrosion-resistant processes applied to the base material. If the ohmic contact itself is not continuous, the shielding effectiveness can be maximized by making the joints between adjacent pieces overlapping rather than abutted.

The shielding effectiveness of an enclosure is further reduced when a wire passes through a hole in the enclosure; RF energy on the wire from an external field is re-radiated into the interior of the enclosure. This coupling mechanism can be reduced by filtering the wire where it passes through the shield boundary.

Given the safety considerations involved in connecting electrical components to the chassis or frame in battery powered vehicles, such filtering will usually consist of a series inductor (or ferrite bead) rather than a shunt capacitor. If a capacitor is used, it must have a voltage rating and leakage characteristics that will allow the end product to meet applicable safety regulations.

The B+ (and B-, if applicable) wires that supply power to a control panel should be bundled with the other control wires to the panel so that all these wires are routed together. If the wires to the control panel are routed separately, a larger loop area is formed. Larger loop areas produce more efficient antennas which will result in decreased immunity performance.

Keep all low power I/O separate from the motor and battery leads. When this is not possible, cross them at right angles.

ELECTROSTATIC DISCHARGE (ESD)

Curtis PMC motor controllers contain ESD-sensitive components, and it is therefore necessary to protect them from ESD (electrostatic discharge) damage. Most of these control lines have protection for moderate ESD events, but must be protected from damage if higher levels exist in a particular application.

ESD immunity is achieved either by providing sufficient distance between conductors and the ESD source so that a discharge will not occur, or by providing an intentional path for the discharge current such that the circuit is isolated from the electric and magnetic fields produced by the discharge. In general the guidelines presented above for increasing radiated immunity will also provide increased ESD immunity.

It is usually easier to prevent the discharge from occurring than to divert the current path. A fundamental technique for ESD prevention is to provide adequately thick insulation between all metal conductors and the outside environment so that the voltage gradient does not exceed the threshold required for a discharge to occur. If the current diversion approach is used, all exposed metal components must be grounded. The shielded enclosure, if properly grounded, can be used to divert the discharge current; it should be noted that the location of holes and seams can have a significant impact on ESD suppression. If the enclosure is not grounded, the path of the discharge current becomes more complex and less predictable, especially if holes and seams are involved. Some experimentation may be required to optimize the selection and placement of holes, wires, and grounding paths. Careful attention must be paid to the control panel design so that it can tolerate a static discharge.

MOV, transorbs, or other devices can be placed between B- and offending wires, plates, and touch points if ESD shock cannot be otherwise avoided.

APPENDIX B

PROGRAMMING DEVICES

Curtis programmers provide programming, diagnostic, and test capabilities for the 1266A/R controller. The power for operating the programmer is supplied by the host controller via a 4-pin connector. When the programmer powers up, it gathers information from the controller.

Two types of programming devices are available: the 1314 PC Programming Station and the 1313 handheld programmer. The Programming Station has the advantage of a large, easily read screen; on the other hand, the handheld programmer (with its 45×60mm screen) has the advantage of being more portable and hence convenient for making adjustments in the field.

Both programmers are available in User, Service, Dealer, and OEM versions. Each programmer can perform the actions available at its own level and the levels below that—a User-access programmer can operate at only the User level, whereas an OEM programmer has full access.

PC PROGRAMMING STATION (1314)

The Programming Station is an MS-Windows 32-bit application that runs on a standard Windows PC. Instructions for using the Programming Station are included with the software.

HANDHELD PROGRAMMER (1313)

The 1313 handheld programmer is functionally equivalent to the PC Programming Station; operating instructions are provided in the 1313 manual. This programmer replaces the 1307 and 1311, earlier models with fewer functions.

PROGRAMMER FUNCTIONS

Programmer functions include:

Parameter adjustment — provides access to the individual programmable parameters.

Monitoring — presents real-time values during vehicle operation; these include all inputs and outputs.

Diagnostics and troubleshooting — presents diagnostic information, and also a means to clear the fault history file.

Programming — allows you to save/restore custom parameter settings files and also to update the system software (not available on the 1307 or 1311).

Favorites — allows you to create shortcuts to your frequently-used adjustable parameters and monitor variables (not available on the 1307 or 1311).

APPENDIX C SPECIFICATIONS

SPECIFICATIONS: 1266A/1266R CONTROLLERS

Nominal input voltage	36–48V
PWM operating frequency	16 kHz
Electrical isolation to heatsink	500 V ac (minimum)
Logic enable and logic power input voltage (minimum)	16.8 V
Logic enable and logic power input current (no contactors engaged)	160 mA without programmer; 200 mA with programmer
Logic input voltage	>20.0 V High; <7.5 V Low
Logic input current	10 mA
Operating ambient temperature range	-40°C to 50°C (-40°F to 122°F)
Heatsink overtemperature cutback	starts at 85°C (185°F); cutoff at 95°C (203°F)
Heatsink undertemperature cutback	50% armature current at -25°C (-13°F)
Package environmental rating	IP5X
Weight	3.9 kg
Dimensions (LxWxH)	275A models: 198 × 114 × 68 mm 350A models: 198 × 114 × 70 mm

MODEL NUMBER	NOMINAL BATTERY VOLTAGE	ARMATURE 2 MIN RATING	FIELD 2 MIN RATING
1266A-52XX	36–48 V	275 A	25 A
1266A-53XX	36–48 V	350 A	30 A
1266R-52XX	36–48 V	275 A	25 A
1266R-53XX	36–48 V	350 A	30 A